

---

**Vortex EF2211/EF2210  
Reference Manual**



Introduction.....	2
<i>Features and Benefits</i> .....	3
Pre-Installation.....	4
<i>EF2211/EF2210 Front and Rear Panels</i> .....	5
Installation .....	6
<i>Mounting the EF2211/EF2210</i> .....	6
<i>Connecting the EF2211/EF2210 to Other Equipment</i> .....	6
<i>Device IDs on the EF Bus</i> .....	8
<i>Connecting Multiple Vortex Devices</i> .....	8
<i>Factory Default Settings (Preset 0)</i> .....	9
<i>Check Surrounding Equipment</i> .....	11
Integrating the Unit Into Your System .....	14
<i>Input Settings</i> .....	14
<i>Calibration</i> .....	14
<i>Set up the Phone Interface (EF2211 Only)</i> .....	16
<i>Build Your Echo Canceller Reference</i> .....	16
<i>Echo Canceller Reference for Multiple Vortex Devices</i> .....	17
<i>Configure the Automatic Microphone Mixer</i> .....	18
<i>Automixer Settings for Multiple Vortex Devices</i> .....	20
<i>Configure the Matrix Mixer</i> .....	21
<i>Building Your System with Multiple Vortex Devices</i> .....	21
The EF Bus .....	23
<i>Presets</i> .....	25
<i>Other EF2211/EF2210 Features</i> .....	25
LCD Menu Structure .....	26
<i>System Menu</i> .....	28
<i>Phone Control (EF2211 Only)</i> .....	29
<i>Inputs</i> .....	30
<i>Outputs</i> .....	31
<i>Automixer Menu</i> .....	32
<i>Matrix Menu</i> .....	34
<i>Parametric EQ Menu</i> .....	35
<i>Presets</i> .....	36
<i>Macros</i> .....	36
Troubleshooting .....	37
<i>Automatic Microphone Mixer</i> .....	37
<i>Matrix Mixer</i> .....	37
<i>Echo Canceller Reference</i> .....	37
<i>Residual Echo</i> .....	37
<i>Contacting Technical Support</i> .....	42
Technical Specifications .....	43
<i>Compliance</i> .....	44
Conference System Design .....	49
EF2211/EF2210 Block Diagram .....	50
Connector Pinouts.....	52
<i>Connecting Unbalanced RCA to Balanced Terminal Block</i> .....	54
<i>Making an EF Bus Terminator</i> .....	54
<i>Additional Notes</i> .....	55
Warranty Information .....	56
Definition of Terms .....	58
Index .....	61

---

---

# ***INTRODUCTION***

---

---

## **Welcome**

Congratulations on your purchase of the Vortex EF2211/EF2210!

## **How to Use This Manual**

This is a reference manual for your EF2211/EF2210. Information specific to the EF2211 or EF2210 will be noted as such. The major difference between the EF2211 and the EF2210 is that the EF2210 does **not** have a phone interface.

This manual is structured to provide the information you need quickly and conveniently. The following is an overview of each section:

- *Introduction*
- *Pre-Installation* includes information about the contents of the box, tools needed for installation and front and rear panel descriptions.
- *Installation* covers connections of inputs/outputs and calibration of inputs of the EF2211/EF2210.
- *Integrating the Unit Into Your System* describes adjustments to take into consideration when integrating the EF2211/EF2210 with surrounding equipment in your system.
- *LCD Menu Structure* describes an overview of the LCD menu structure and also gives a system overview of features and options available.
- *Troubleshooting* helps to debug problems with installation.
- *Technical Specifications* provides the technical specifications of the EF2211/EF2210.
- *Conference System Design* gives suggestions on topics to consider when designing your system.
- *EF2211/EF2210 Block Diagram* shows the inside of the EF2211/EF2210.
- *Connector Pinouts* shows pinout diagrams for EF2211/EF2210 input and output connectors.
- *Warranty Information*
- *Definition of Terms* explains terms used in this manual, as well as terms used in our technology of echo cancellation, noise cancellation, and audio conferencing.

## **About the EF2211/EF2210**

The EF2211/EF2210 features industry-leading acoustic echo cancellation technology, which keeps received audio from being re-transmitted to its original location, and patented noise cancellation algorithms which dramatically reduce ambient noise in the audio sent to other sites without affecting speech quality.

Also included in the microphone input is a neural network Automatic Gain Control that reacts only to valid speech patterns to bring voices within desired levels. AGC controls are user-adjustable, as are settings for the 5-band parametric EQ offered on all input and output channels in the EF2211/EF2210.

The EF2211 includes a telephone interface with ambient noise cancellation, which can dramatically improve the receive audio quality on phone calls.

The EF2211/EF2210 may be programmed directly from the front panel, or through our Conference Composer software (included), which programs the unit via RS-232. The unit may additionally be controlled via external RS-232 devices.

**Product  
Registration**

Please take a moment to fill out and return your registration card. This information will help us to provide you with better customer support and will allow us to notify you with updated product features and software.

***FEATURES AND BENEFITS***

---

- 1 mic/line input, 2 line inputs, 3 line outputs
- Includes a telephone hybrid, with noise cancellation, for adding phone calls to conferences
- Country specific telephone configuration setting allow use almost anywhere
- 10 Watt power amplifier for driving audio in the room
- Industry-leading acoustic echo and noise cancellation ensure the highest possible audio quality between sites
- Includes matrix mixer with arbitrary cross point gain values
- Ambient noise cancellation on mic/line input and telephone receive audio
- 5-band parametric EQ on all inputs and outputs
- Up to 32 user configurable presets, 16 factory presets, and 256 macros for flexible control
- May be linked with other Vortex devices via the EF Bus including EF2280, EF2241, EF2211, EF2210, EF2201, or other Polycom products

## PRE-INSTALLATION

### What's Included

The Vortex EF2211/EF2210 product package includes the following items:

- Vortex EF2211/EF2210 Reference Manual
- Vortex EF2211/EF2210
- External power supply
- Cat 5 cable for EF Bus
- Telephone cable (NOT included with the EF2210)
- Rack mount screws (4)
- 3.5 mm terminal block connectors (6)
- Cable clamp and screw
- CDROM containing other manuals and Conference Composer software
- Product Registration Card




Figure 1. What's Included with your Vortex EF2211/EF2210.

### What's Not Included


The following equipment is not included with the EF2211/EF2210 product package, but may be necessary to create a completely functional system:

- Microphones
- Loudspeakers
- Audio cables
- Videoconferencing codec or other four-wire interface (optional)
- RS-232 remote control device (optional)

### Tools Needed for Installation

- Screwdriver to mount the EF2211/EF2210 in your rack.
- 3.5 mm terminal block connector screwdriver

## EF2211/EF2210 FRONT AND REAR PANELS



**Figure 2.** EF2211/EF2210 Front and Rear Panels

1. LCD DISPLAY. Displays menu instructions for configuration and operation of the EF2211/EF2210.
2. DOWN BUTTON. Scrolls backward through menu items at a particular level or decreases the value of a parameter.
3. UP BUTTON. Scrolls forward through menu items at a particular level or increases the value of a parameter.
4. ENTER. Enters the menu and allows you to select and change parameter values.
5. ESC. Returns to the next highest level of menus.
6. HOME. Returns to the top of the menu structure.
7. LEVEL INDICATOR. Indicates the level of the selected channel or parameter.
8. PHONE CONNECT. Takes the phone line on or off hook. If you have an analog handset connected to the PHONE jack on the back panel, pushing this button will disable the PHONE jack while enabling the LINE jack (see Item 17).  
\* **This feature is not available on the EF2210.**
9. MIC ACTIVITY LED. Indicates gating activity on the mic/line channel input.
10. INPUT PARALLEL PORT. Parallel logic input.  
\* **This feature is not available on the EF2210.**
11. OUTPUT PARALLEL PORT. Parallel logic output.  
\* **This feature is not available on the EF2210.**
12. EF BUS IN. Connects to EF BUS OUT of another Vortex device.
13. EF BUS OUT. Connects to the EF BUS IN of another Vortex device.
14. RS-232 SERIAL PORT. Connect this to an optional RS-232 remote control device, such as a touch panel or personal computer COM port.
15. POWER SUPPLY INPUT. Connects to the external power supply provided with the EF2211/EF2210.
16. POWER AMPLIFIER OUTPUT. Drives up to 10 W into 4-16 Ohm speakers.
17. PHONE/LINE JACKS. Use the PHONE jack for connecting an analog handset to the system. Use the LINE jack for connecting to an analog telephone line.  
\* **This feature is not available on the EF2210.**
18. INPUTS. Includes inputs for a microphone or line level input, remote end audio (line level), and program audio (line level).
19. LINE OUTPUTS. Line level outputs for an amp, remote audio, and record audio.

---

## ***INSTALLATION***

---

---

This equipment is intended to only be installed by qualified service personnel. The equipment shall be connected to a socket-outlet that provides a protective earthing connection.

### **North American Requirement**

CAUTION-To reduce the risk of fire, use only No. 26 AWG or larger telecommunication line cord.

---

### ***MOUNTING THE EF2211/EF2210***

---

The EF2211/EF2210 can be mounted in a rack enclosure using four large screws (10-32x1/2") included with the unit. One EF2211/EF2210 fits in a single rack space.

### **Recommendation For Easy Access**

While not required, leave a single rack space in between the EF2211/EF2210 and other units in your rack. This gives you easier access to the back panel.

### **Instructions for Securing Power Supply to Back of EF2211/EF2210**

- Locate the cable clamp on the back panel of the EF2211/EF2210 above the power connector.
- Remove the screw and thread the power cord through the cable clamp.
- Attach the cable clamp to the back panel of the EF2211/EF2210 and tighten the screw. Align the clamp so that the power cable does not interfere with the connectors on the EF2211/EF2210 back panel.
- Plug in the power supply.
- We recommend that you also Ty-wrap the power supply to the rack. The purpose of securing the power supply to the back panel is so that if the power supply were to drop, it would pull where the cord is attached with the cable clamp and not pull the plug out of the EF2211/EF2210.

---

**Caution!** *Do not use any other power supply other than the one provided with this unit.*

---

---

### ***CONNECTING THE EF2211/EF2210 TO OTHER EQUIPMENT***


---

### **Grounding**


The EF2211/EF2210 has 1 mic/line input plus 2 line level inputs and 3 line level outputs. Each input/output is "Pin 1 compatible" — this means that the ground pin of each input/output is tied to chassis ground. Chassis ground is connected to the input power ground.

## Typical EF2211/ EF2210 Connections

The EF2211/EF2210 will typically be connected to other equipment in a single room setup as shown below in Figure 3 and Figure 4.



**Figure 3.** Block diagram of typical EF2211/EF2210 connections: a single room using one device.  
NOTE: The phone interface is not available on the EF2210.



**Figure 4.** Typical EF2211/EF2210 connections.  
NOTE: The phone interface and parallel logic ports are not available on the EF2210

The following steps are typically used to set up the EF2211/EF2210:

- Connect a microphone or line level microphone mix into the MIC INPUT. Each

input accepts 3.5 mm terminal block connectors. See “Connector Pinouts” on page 52 for pinouts of the terminal block connectors.

- Connect SPEAKER OUTPUT to loudspeaker or AMP OUTPUT to the room amplifier.
- If RS-232 remote control is desired, connect the RS-232 REMOTE CONTROL port of the EF2211/EF2210 to the remote control device, such as an RS-232 interface to a touch panel or a COM port on a personal computer.
- On the EF2211, connect the LINE RJ11 jack to an analog telephone line.
- On the EF2211, connect the PHONE RJ11 jack to an analog telephone set (optional).
- Connect the external power supply to the POWER SUPPLY INPUT jack of the EF2211/EF2210.
- Set the country code on the EF2211. By default the phone interface will be disabled until you select a country code for the telephony interface. This can either be done with the front panel LCD menu, or the RS-232 interface. The country code only needs to be selected the first time or when the country of the installation is changed.

## DEVICE IDS ON THE EF BUS

When considering which Device IDs can be used for which Vortex device, decide how many devices have the ability to **transmit** on the W, X, Y, and Z busses, and how many have the ability to transmit on the P Bus. The EF2210, for example can only transmit on the W, X, Y, and Z busses while the EF2211 can transmit on the W, X, Y, and Z busses as well as the P bus. Up to 8 devices can transmit on the W, X, Y, and Z busses. Similarly, up to 8 devices can transmit on the P bus. Note that the EF2211 counts as one of both types. All devices that can transmit on the same bus output(s) must have unique device IDs. If the device IDs of linked Vortex devices are the same, the front panel LCD screen will display “EFBus Error: Dev. ID Conflict”.

## CONNECTING MULTIPLE VORTEX DEVICES

Up to 8 echo cancellation Vortex devices in combination can be linked together at one time and up to 8 phone interface Vortex devices in combination can be linked together at one time (See Device IDs on the EF Bus above). Keep in mind that there are units that are considered one of both types (such as the EF2241 or EF2211). Each unit in the chain must have a unique Device ID. Use the EF Bus to link multiple Vortex devices together.

The following steps should be followed to connect the EF Bus:


1. Set a unique Device ID for each Vortex device. The Device IDs range from 00 to 07.
2. Power off all units.
3. Connect the RS-232 remote control device to any Vortex device in the chain.
4. Connect the provided Cat-5 cable between the EF BUS OUT of the first device, and the EF BUS IN of the second device.

**Note.** *The EF Bus must be connected so that the EF Bus In of one box is connected to the EF Bus Out of another. Connecting the EF Bus In to another EF Bus In (or Out to Out) will not work.*

5. Connect another Cat-5 cable between the EF BUS OUT of the second device and the EF BUS IN of the third device, and so on.
6. Power on all units at the same time.

## Terminating the EF2211/EF2210

The EF2211/EF2210 is self-terminating so its EF Bus does NOT need to be terminated. However, if you are linking the EF2211/EF2210 to EF2280s, terminate the EF Bus link.



**Figure 5.** Only the EF2280 needs to be terminated when linked together with EF2211/EF2210s.

## FACTORY DEFAULT SETTINGS (PRESET 0)

The following is a list of the factory default settings of the EF2211/EF2210. Since the microphone and other equipment in your application may have different nominal levels, you can start with a FACTORY PRESET (Presets 0-15), change it to match your environment and then save it within the EF2211/EF2210 as a USER PRESET (Presets 16-47). Once you've saved a USER PRESET, set the POWER ON PRESET to that USER

PRESET (or whichever preset you want to come up after power up). The unit will need to be configured for your system.

PROGRAM PARAMETERS	FACTORY DEFAULT PRESET VALUE
<b>SYSTEM PARAMETERS</b>	
Preset	0
Device ID	0
Baud Rate	9600
Flow Control	Off
<b>INPUT CHANNELS</b>	
Acoustic Echo Cancellation (Input 1)	On
Automatic Gain Control (AGC), Input 1	On
AGC Rate (Input 1)	1 dB/s
AGC Maximum (Input 1)	3 dB
AGC Minimum (Input 1)	-3 dB
Echo Canceller Reference (Input 1)	Ref1
Filtering	Off
Input Gains	Mic Mode + 15 dB = 48 dB for Input 1 0 dB for Inputs A-B
Mute	Off
Noise Cancellation (Input 1)	On
Noise Cancellation Level (Input 1)	10 dB
Phantom Power (Input 1)	On
<b>OUTPUT CHANNELS</b>	
Mute	Off
Output Gain	0 dB
<b>PHONE CONTROL (EF2211 ONLY)</b>	
Auto Answer	Off
Auto Hangup Call Progress	Off
Auto Hangup Loop Drop	Off
Dial Tone Gain	0 dB
DTMF Gain	0 dB
Ring Tone Enable	On

PROGRAM PARAMETERS	FACTORY DEFAULT PRESET VALUE
Entry and Exit Tone Enable	On
<b>PHONE INPUT (INPUT T), EF2211 ONLY</b>	
Automatic Gain Control (AGC)	On
AGC Maximum	12 dB
AGC Minimum	-6 dB
AGC Rate	1 dB/s
Phone Input Gain	0 dB
Mute	Off
Noise Cancellation	On
Noise Cancellation Level	5 dB
Line Echo Cancellation	On
Dynamics Processing	On
Filtering	Off
<b>PHONE OUTPUT (OUTPUT T), EF2211 ONLY</b>	
Mute	Off
Phone Output Gain	0 dB
Dynamics Processing	On
Filtering	Off

**Presets and Multiple Vortex Devices**

PRESET 0 is preconfigured for a system with multiple Vortex devices. In Preset 0, the microphone is bussed out to other units on the W Bus. Microphones are also input into each device on the W Bus (INPUT WM0 in the Matrix).

If you have multiple devices in your system, save settings to a user preset (Presets 16-47) on each device. Saving a preset will only save the preset on that particular unit so save the preset to each Vortex device. Also, remember to set the POWER ON PRESET on each device to the User Preset that you have saved your settings to otherwise the device will revert back to Preset 0 (factory default) if power is lost.

*CHECK SURROUNDING EQUIPMENT*

Now that the physical connections to the EF2211/EF2210 are set up, it may be necessary to check the surrounding equipment to make sure levels are set correctly. The following suggestions may be helpful in integrating the EF2211/EF2210 into your system:

**Pick a Standard Signal Level**

A standard nominal signal level should be used throughout the audio system. Any equipment that does not operate at this standard level should be compensated for as

close to the piece of equipment as possible. A 0 dB nominal level is a good standard signal level. For example, a consumer VCR will probably generate a -8 dBu level. As soon as the VCR signal arrives at an input with some gain control, the input gain should be adjusted so that you get a 0 dB level, i.e. adding 8 dB of gain.

## Check Levels to the Codec

### **Configure the matrix mixer output to the codec input.**

The output gain of the matrix mixer should be set to match the nominal input level of the codec. For example, if the codec accepts -10 dBV (-8 dBu) inputs, 8 dB of attenuation should be applied at the matrix mixer output to the codec.

### **Configure the matrix mixer input from the codec output.**


The input gain of the matrix mixer should be set to match the nominal output level of the codec. For example, if the codec outputs a -10 dBV (-8 dBu) level, 8 dB of gain should be applied on the matrix mixer input. This will bring the codec level up to 0 dBu inside the matrix.

## Verify Room Gain

After adjusting the loudspeaker level, verify the room gain in your system using the ROOM GAIN meter on the DIAGNOSTICS page of Conference Composer. Room gain refers to the relative level of the audio going to your amplifier (remote end speech or telephone speech) and the level of this audio being picked up by the microphone. The Room Gain measurement is only accurate when just the remote talkers are speaking. If local talkers are speaking too, the room gain meters are not accurate. See Figure 6 below. The meter shows the room gain, which is the relative level of the output level and the input level. While the EF2211/EF2210 will operate in positive room gain conditions, the room gain should be around 0 dB or a negative value. If you have a positive room gain, make adjustments in the following areas:

1. Decrease the Input Gain of the microphone.
2. Decrease the Output Gain of the microphone.

- OR adjust the placement of the microphone relative to the loudspeaker.



**Figure 6.** Room Gain Meter on the Diagnostics page of the Conference Composer control software.

## Configure Program Audio Sources

Set the gain on the matrix mixer input from the program audio source so that program audio is played into the room at a level similar to that of speech from the remote site. This should also ensure that the program audio level is good when sent to the remote site.

## ***INTEGRATING THE UNIT INTO YOUR SYSTEM***

---

---

### **Operating the EF2211/EF2210**

The EF2211/EF2210 can be operated in two ways: through the LCD menu on the front panel or through RS-232. For control via RS-232, please refer to the EF2211/EF2210 Programming Guide, which includes programming tips as well as the EF2211/EF2210 RS-232 commands. For operation using the PC control software, Conference Composer, please refer to the Conference Composer User Guide.

Use Conference Composer software to easily configure the EF2211/EF2210 with a PC, or refer to the Applications Guide for different configurations that are already programmed into factory presets.

### ***INPUT SETTINGS***

---

#### **Set Input 1 for Mic or Line Level**

Configure Input 1 for mic or line level using the LCD menu (See “Level (Input 1)” on page 30) or Conference Composer Control Software (See the Conference Composer User Guide). Setting the input to mic level adds 33 dB of gain to the input stage. If you are connecting one microphone to the device, choose Mic level (with the default input gain value of 15 dB, a total of 48 dB of gain is applied to the input). If you are connecting an external automatrix microphone mixer to the input, choose Line level.

#### **Select Phantom Power for Input 1**

Turn phantom power On or Off for Input 1 using the LCD menu (See “Phantom Power (Input 1)” on page 30) or Conference Composer Control Software (See the Conference Composer User Guide). Phantom power should be turned On for condenser and electret microphones.

#### **Set Levels on Line Input Channels**

Set the line input channel gains (Channels A-B) to match the nominal level of the incoming equipment. The line inputs have a maximum nominal level of 0 dBu. If your incoming line level inputs have a higher nominal level than 0 dBu you will want to use a pad to remove the level.

If you are connecting from equipment that has RCA plugs, you will most likely need 8 dB of gain on the Input and -8 dB of gain on the Output.

### ***CALIBRATION***

---


When using the factory default, Preset 0, the following calibration can be used.

#### **Set Mic/Line Input Gain**

In Preset 0, Automatic Gain Control (AGC) is On and the microphone gain on Input 1 is set to 15 dB. The AGC will compensate for the microphone gain. If you are using a ceiling microphone, set the microphone gain to 28 dB.

**Fine tune the Input Gain using the Automatic Gain Control (AGC) meter on Conference Composer Software.**

In the Conference Composer Software, go to the DIAGNOSTICS page. Watch the meter labelled AGC while someone is talking into the particular channel that you are adjusting. Watch the number in the box at the bottom of the AGC meter (See Figure 7 below). This is the amount of gain that the AGC is applying. The goal is to have the AGC meter on average staying around 0. If the level that you see in the box is negative, decrease the input gain by the average number that you see in the box because the AGC is attenuating the channel’s input gain because the level is too high. If the number in the box is positive, increase the input gain on that channel because the AGC is boosting the signal because it is too low. For example, if the meter is showing an average gain of -15 dB, you should increase your input gain by 15 dB. If the meter shows an average gain of +10 dB, you should decrease your input gain by 10 dB.



**Figure 7.** AGC Meter on the Diagnostics page of the Conference Composer software. The gain adjustment is the same gain control on the Mic/Line Inputs page in Conference Composer.

IF THE AGC METER SHOWS...	ADJUST THE INPUT GAIN IN THIS WAY.
positive gain	Increase gain by the level shown in the box.
negative gain	Decrease gain by the level shown in the box.

**Table 1:** How to set the Input Gain using the AGC meter on the Conference Composer Diagnostics page.

an average level of 0 dB	You've set the Input Gain to a good level!
--------------------------	--

**Table 1:** How to set the Input Gain using the AGC meter on the Conference Composer Diagnostics page.

**Customize Setting for Your Particular Application**

The following sections will describe customizing parameters on the EF2211/EF2210 for your particular application if you are not using Preset 0.

***SET UP THE PHONE INTERFACE (EF2211 ONLY)***

The echo canceller reference of the EF2211 is by default set up with the phone input already assigned to it.

By default the phone interface will be disabled until you select a country code for the telephony interface. This can either be done with the front panel LCD menu, or the RS-232 interface. The country code only needs to be selected the first time or when the country of the installation is changed.

Send audio from the phone to the outputs on the same device by unmuting the cross-point of Input T on that output. Send audio from the phone to other linked devices by using the P bus output in the EF Bus. The linked devices can take the phone signal off the bus from the P Bus input.

***BUILD YOUR ECHO CANCELLER REFERENCE***

The acoustic echo canceller (AEC) reference should generally contain exactly the same audio signals as what is coming out of your loudspeaker(s) minus any local microphone(s) that might be used for sound reinforcement, since the signal output from the loudspeaker is what is then picked up by the room's microphones causing acoustic echo. Note that this statement is a general statement. Conditions for this being true follow:

**If your system does NOT have sound reinforcement,**

- The AEC reference should contain exactly the same audio as the loudspeaker output: all far end audio, audio from the phone add, program audio, etc.
- If you are using crosspoint gains in the loudspeaker mix, apply the same gains to the signals in your reference.

**If your system has sound reinforcement,**

- Do NOT mix your room microphones into the reference, but include all other audio (program audio, remote audio, phone audio, etc.).

## ECHO CANCELLER REFERENCE FOR MULTIPLE VORTEX DEVICES

In a system with multiple devices, we recommend that one device be designated as the unit that provides the EF bus reference for the acoustic echo cancellers. This unit takes its reference signals and places it on the EF bus. All other units that are linked together may use the EF bus reference as the reference for their echo canceller, or they can use their own internal reference(s). The reference may include a mix of any input, with crosspoint gains, including W, X, Y, and Z busses. Set the EF Bus Reference in the System Menu of the LCD Menu (See “EF Bus Reference” on page 28).

### Setting up the Bus Reference

### If all far end audio and program audio sources are on the same Vortex device.

1. Assign far end audio and program audio sources to Reference 1 on the originating device.
2. On the EF Bus page in Conference Composer for the originating device, set the Exported Signals to REFERENCE 1. Only one device can put an echo canceller reference on the EF Bus as the Bus Reference.
3. On all linked devices, set the echo canceller reference to BUS.

For example, a system uses 1 EF2211, 1 EF2280, and 1 Polycom VS4000 video codec. The Reference 1 is set up on EF2280 with ID 0. The Matrix for this EF2280 in Conference Composer is shown in Figure 8 and the EF Bus page in Figure 9. Conference Composer will not allow more than one device assign their echo canceller reference as the Bus Reference. Notice that the phone audio and VS4000 inputs are both assigned to Reference 1 on the originating EF2280. The Matrix for any linked devices is shown in Figure 10.

The matrix shows connections for various inputs and outputs. The columns represent different signal paths: IN 1-8, To VS4000, Rm Spk, Dupl u/W, Dupl u/X, Dupl u/Y, Dupl u/Z, Reference 1, Reference 2, Mixer, and AEC. The rows list inputs such as Mic 1-8, From VS4000 (A, B, C, D), Mics 9-12 (wM0-wM2, yM0-yM2), and Phone Audio (PM0, PM1). The matrix is populated with 0s and 1s, indicating signal flow. Reference 1 is set to 1 for Mic 1, Mic 2, Mic 3, Mic 4, Mic 5, Mic 6, Mic 7, and Mic 8. Reference 2 is set to 1 for Mic 7 and Mic 8. The AEC column is set to 1 for Mic 1, Mic 2, Mic 3, Mic 4, Mic 5, Mic 6, Mic 7, and Mic 8.

Figure 8. Matrix page of origin EF2280 (ID 00)

The EF Bus page shows configurations for W, X, Y, and Z busses. Each bus has a table of EFBus wB0-wB7, xB0-xB7, yB0-yB7, and zB0-zB7. The 'Exported Signals' section at the bottom shows 'Current Unit Exporting Signal' set to 'EF2200:00'. A note states: 'Note: Only one unit can place a reference signal on the EFBus at one time. If you need to create a reference signal across multiple units, use the W, X, Y, and Z bus channels.'

Figure 9. EF Bus page of origin EF2280 (ID 00)

The image shows a matrix page titled 'OUTPUTS' with a 'Safety Mute' indicator. The table lists various input and output channels. The columns are labeled IN, 1, 2, 3, 4, 5, 6, 7, 8, A, B, C, D, W, X, Y, Z, R1, R2, Mover, and AEC. The rows include Mic 9, Mic 10, Mic 11, Mic 12, and a section for INPUTS (D, wM0-wM2, YM0-YM2, ZM0-ZM2, FM0-FM2, Signal Generator). The matrix contains numerical values (0, 15, 0n) and bus assignments (1 Bus, 2 Bus, 3 Bus, 4 Bus). At the bottom, there are control buttons: Find, Not Muted, Muted, Automixer 1, and Automixer 2.

Figure 10. Matrix page of linked devices

**If far end audio and program audio sources are on several Vortex devices.**

1. Bus each far end audio and program audio source to each device. Do this by assigning each signal input to either the W, X, Y or Z bus.
2. Assign an echo canceller reference on each device that will include all far end audio and program audio sources.

**CONFIGURE THE AUTOMATIC MICROPHONE MIXER**

The EF2211/EF2210 contains one automatic microphone mixer. Input 1 may be assigned to automatic mixer 1 or no automatic mixer. Set the input channel to use neither automatic mixer if an input is not actually a microphone, but is a program audio input.

If you have a PC, use the Conference Composer software (See the Conference Composer User Guide) to set the automixer parameters. If you would like to set automixer parameters using the LCD menus, see “Automixer Menu” on page 32 for instructions on setting automixer parameters.

**Automixer Parameters**

The following parameters configure how the EF2211/EF2210 automatic microphone mixer operates. Parameters include the following: Decay Time, Hold Time, Camera Gating Threshold, Chairman Mode, Chairman Mic, Last Mic On Mode, Last Mic Number, Local Max NOM, Global Max NOM, Automixer Reference, Reference

Bias, Off Attenuation, Threshold Type, Gating Mode, Adaptive Threshold, Manual Threshold, and Gate Priority.




Figure 11. Off Attenuation, Hold Time, Adaptive Threshold, and Decay Time.

## Global Settings.

**Decay Time.** Decay time is the amount of time the microphone audio takes to ramp down to the Off Attenuation level after Hold Time. Decay Time values range from 0 to 5000 msec. The default value is 1000 msec.

**Hold Time.** This is the amount of time the microphone stays On after the energy in the channel drops below the gating threshold. The default value is 500 msec. The range is 1 to 5000 msec. Microphone channels gating On and Off too frequently during short pauses in speech might be the result of setting the Hold Time too low while too many microphones gating on at the same time may be the result of Hold Time values that are too high.

**Camera Gating Threshold.** Specifies the hold time for camera gating information.

## Mixer Settings.

**Bus Mixer.** This command is used to assign the automixer to one of the EF Bus automixer groups. Setting the Bus Mixer to the same number as the automixer on another Vortex device will allow the devices to be one large automixer. Setting Bus Mixer to 0 means that the automixer is not grouped on the EF Bus and the automixers operate independently.

**Chairman Mode.** Enables or disables Chairman Mode for the automixer.

**Chairman Mic.** Sets the Chairman Microphone for the automixer.

**Last Mic On Mode.** Sets “Last Mic On” mode for the automixer.

**Last Mic Number.** Sets the microphone number that will remain on when “Last Mic On” mode is set to manual. Setting this value to 0 will cause the automixer to leave the last open microphone on. The last microphone number is specified for the automixer, but is only used in manual “Last Mic On” mode.

**Local Max NOM.** Sets the maximum number of open microphones (NOM) limit for the automixer. This NOM limit is a “local” limit, meaning that this limit applies only to the specific Vortex device that it is set on.

**Global Max NOM.** Sets the global maximum number of open microphones (NOM) limit for each linked automixer. The maximum value for this command is 64. This NOM limit is a “global” limit, meaning that this limit applies to all linked automixers with the same Bus ID.

**Off Attenuation.** Sets the Off Attenuation (in dB) for the automixer. Setting

this value to 18 would result in the microphone signals being attenuated by 18 dB when gated off. This value is set independently for the automixers.

**Automixer Reference.** When enabled, the echo canceller reference becomes a muted input in the automix so that far end audio coming from the speakers does not gate on local microphones.

**Reference Bias.** Adjusts how much gain is applied to the Automixer Reference signal. The higher the gain, the harder it will for local talkers to gate on a microphone.

### Channel Settings.

**Automixer.** This allows you to select between no automixer and Mixer 1 for Input 1.

**Threshold Type.** Sets adaptive or manual automatic gating thresholds per input. The default is adaptive.

**Gating Mode.** Sets the automixer gating control mode for the input channel 1. The possible modes are Normal Gating, Microphone Forced On, or Microphone Forced Off.

**Adaptive Threshold.** This allows you to determine when to gate a microphone on based on an estimate of the background noise level. The default value is to gate a channel on if it is more than 10 dB louder than the background noise level. Values range from 0 to 100 dB. To set the Adaptive Threshold, scroll through the Adaptive Threshold range and select the desired Adaptive Threshold by pressing ENTER.

**Manual Threshold.** Sets the automixer gating threshold for input channel 1. This value is only used if the input set to Manual Gating via the THRESHOLD TYPE option.

**Gate Priority.** The priority of each microphone can be assigned a value ranging from 1 to 4. Priority 1 microphones have priority over priority 4 microphones for gating. The default is to have all microphones set to priority 1. If Chairman Mode is enabled, all microphones including ones with priority of 1 will be gated off when the Chairman mic gates on.

## AUTOMIXER SETTINGS FOR MULTIPLE VORTEX DEVICES

When using more than one Vortex device in your room system, you have several possibilities for how you configure the automixer. Each device can operate as one of the following:

- One automixer, independent of other devices linked to it
- Two automixers, independent of other devices linked to it (applies only to Vortex devices with 2 automixers)
- One large automixer, sharing automixer functions with other devices linked to it
- Two large automixers, sharing automixer functions with other devices linked to it (applies only to Vortex devices with 2 automixers)




Figure 12. Vortex device Automixer Settings in Conference Composer Software

## **Automixer and Bus Mixer Settings**

To operate the Vortex device in any of the above possibilities, two global parameters need to be changed: the AUTOMIXER and the BUS MIXER (see Figure 12). The AUTOMIXER parameter chooses which automixer the input channel will be on (this is changed either on the AUTOMIXER page in Conference Composer or on the MATRIX MIXER page).

The BUS MIXER parameter is used to assign one of the two internal automixers to one of the EF Bus automixer groups. For example, consider three Vortex devices, each of which has 2 microphones assigned to Automixer 1 and 2 microphones assigned to Automixer 2. Now, if each of these devices sets their Automixer 1 to have Bus ID 5, then the three automixers (one from each device) will work as a single automixer containing 6 (3 x 2) microphones. Setting BUS MIXER to 0 means that the automixer is not grouped on the EF Bus.

## **Operating as an Independent Automixer**

To set the Vortex device to operate as an independent automixer (or two), set the BUS MIXER parameter to 0, or to a number that is different from any other automixer group on the EF Bus.

## **Operating as One Automixer with Multiple Vortex Devices**

To set the Vortex device to operate as one automixer across several devices, set the BUS MIXER parameter on all devices to the same automixer group.

## **Default Settings**

In the default preset (Preset 0), the Bus Mixer for Automixer 1 is set to 1 and the Bus Mixer for Automixer 2 is set to 2. This means that in the default mode, all linked devices will work together as one complete automixer.

---

## *CONFIGURE THE MATRIX MIXER*

---

The matrix mixer allows arbitrary crosspoint gains in 1 dB increments between any input and output signal.

If you have a PC, use the Conference Composer software (See the Conference Composer User Guide) to set the matrix parameters. If you would like to set matrix parameters from the LCD menus, see “Matrix Menu” on page 34 for descriptions and instructions on setting matrix mixer parameters.

---

## *BUILDING YOUR SYSTEM WITH MULTIPLE VORTEX DEVICES*

---

The following is a checklist for building a system with multiple devices:

1. Assign Inputs.
2. Assign Outputs.
3. Configure submatrix (the EF Bus).
4. Configure your echo canceller reference.

### **1. Assign Inputs**

Assign each audio source to an input. Remember to include the conferencing equipment such as a video codec and any program audio.

### **2. Assign Outputs**

Try to assign as many outputs as you can to one Vortex device to make a simpler submatrix. The bussing gets more complicated if you choose to spread your outputs over several units.

### **3. Configure the submatrix.**

To link multiple devices together, use the submatrix on the EF Bus to configure which signals to receive from other devices that have put their signals on the Bus.

---

---

## ***THE EF BUS***

---

---

The EF Bus is a high speed, low delay digital bus that includes the W, X, Y, and Z audio busses, the P bus, as well as the echo canceller bus reference and remote control information (for other EF devices). It can link up to 8 Vortex devices.

**The W, X, Y, Z Busses.** The W, X, Y, and Z busses include NOM information and can be used for sharing microphone inputs, or for sharing mono or stereo program information. On the EF Bus page in Conference Composer, the inputs coming in to each submatrix labelled WB0, WB1, ... WB7 correspond with the device ID of the bus that is transmitting. The “B” denotes Bus. The submixes themselves, denoted as WM0, WM1, and WM2 are mixes that are input into the main matrix. The “M” denotes Mix.

The EF2211 and EF2210 can transmit and receive signals on the W, X, Y, and Z busses.

**The P Bus.** The P Bus is provided specifically to allow devices to share digital phone audio from the phone hybrid devices (EF2241, EF2201, EF2211).

On the EF Bus page in Conference Composer, the inputs coming in to each submatrix labelled PB0, PB1, ... PB7 correspond with the device ID of the bus that is transmitting. The “B” denotes Bus. The submixes themselves, denoted as PM0, PM1, and PM2 are mixes that are input into the main matrix. The “M” denotes Mix.

The EF2211 can both transmit and receive signals on the P bus. The EF2210 cannot transmit but can receive signals on the P bus.

**Crosspoint Mix Minus Bus.** Each Vortex device in the system can create up to 5 output mixes, depending on what signals they can transmit, and place them on the bus. Each device also can create three input mixes from each of the input busses of the other devices. The mixes allow crosspoint gains to be adjusted on the signals

from the other devices. See Figure 13 below. The input mixes become inputs to the main matrix and can be mixed with the other inputs to create output mixes.

**FROM EF BUS**

Safety Mute

EFBus WB0	EFBus WB1	EFBus WB2	EFBus WB3	EFBus WB4	EFBus WB5	EFBus WB6	EFBus WB7		
WB0	WB1	WB2	WB3	WB4	WB5	WB6	WB7		
	0	0	0	0	0	0	0	WM0	SubMix WM0
	0	0	0	0	0	0	0	WM1	SubMix WM1
	0	0	0	0	0	0	0	WM2	SubMix WM2

EFBus XB0	EFBus XB1	EFBus XB2	EFBus XB3	EFBus XB4	EFBus XB5	EFBus XB6	EFBus XB7		
XB0	XB1	XB2	XB3	XB4	XB5	XB6	XB7		
	0	0	0	0	0	0	0	XM0	SubMix XM0
	0	0	0	0	0	0	0	XM1	SubMix XM1
	0	0	0	0	0	0	0	XM2	SubMix XM2

EFBus YB0	EFBus YB1	EFBus YB2	EFBus YB3	EFBus YB4	EFBus YB5	EFBus YB6	EFBus YB7		
YB0	YB1	YB2	YB3	YB4	YB5	YB6	YB7		
	0	0	0	0	0	0	0	YM0	SubMix YM0
	0	0	0	0	0	0	0	YM1	SubMix YM1
	0	0	0	0	0	0	0	YM2	SubMix YM2

EFBus ZB0	EFBus ZB1	EFBus ZB2	EFBus ZB3	EFBus ZB4	EFBus ZB5	EFBus ZB6	EFBus ZB7		
ZB0	ZB1	ZB2	ZB3	ZB4	ZB5	ZB6	ZB7		
	0	0	0	0	0	0	0	ZM0	SubMix ZM0
	0	0	0	0	0	0	0	ZM1	SubMix ZM1
	0	0	0	0	0	0	0	ZM2	SubMix ZM2

EFBus PB0	EFBus PB1	EFBus PB2	EFBus PB3	EFBus PB4	EFBus PB5	EFBus PB6	EFBus PB7		
PB0	PB1	PB2	PB3	PB4	PB5	PB6	PB7		
0	0	0	0	0	0	0	0	PM0	SubMix PM0
0	0	0	0	0	0	0	0	PM1	SubMix PM1

Not Muted     Muted     Fixed

Exported Signals

AEC Reference

- None
- Reference 1
- Reference 2

Current Unit Exporting Signal: <none>

Note: Only one unit can place a reference signal on the EFBus at one time. If you need to create a reference signal across multiple units, use the W, X, Y, and Z bus channels.

T  
O  
M  
A  
T  
R  
I  
X

Figure 13. W, X, Y, and Z submatrices, the P submatrix, and Exported Bus Reference.

**EF Bus Reference.** In a system with multiple devices, if all devices need the same echo canceller reference, one device should be designated to put its echo canceller reference on the EF bus to be used as the EF Bus Reference. All other devices may use the EF bus reference as the reference for their echo cancellers, or they can use their own internal references. The references may include a mix of any input, with crosspoint gains, including W, X, Y, and Z busses.

**NOM.** The W, X, Y, and Z busses on the EF Bus contain NOM information. See “NOM Active” on page 31 for more information on how NOM attenuation is applied.

**Note.** The EF Bus must be connected so that the EF Bus OUT of one Vortex device is connected to the EF Bus IN of another Vortex device. Connecting EF Bus IN to another EF Bus IN (or EF Bus OUT to EF Bus OUT) will not work. See “Connector Pinouts” on page 52 for pinout of Cat 5 cable.

## 4. Configure Your Echo Canceller Reference

Review what inputs need to be included in your echo canceller reference — See “Build Your Echo Canceller Reference” on page 16. Remember that each microphone needs to have an echo canceller reference. If all microphones are in the same

room and use the same reference, configure the echo canceller reference on one Vortex device and assign it to the EF Bus as the EF Bus Reference. Only one Vortex device out of multiple units linked together can put an echo canceller reference on the EF Bus. For each additional unit, assign the echo canceller reference to use the EF Bus Reference.

For systems with more than one room, you may need to use the W, X, Y, or Z sub-buses to share the echo canceller reference in your additional rooms if the EF Bus Reference has already been assigned to the EF Bus.

## *PRESETS*

---

After configuring your Vortex device, save your settings to a User Preset (PRESETS 16-47). Also, set the POWER ON PRESET to the User Preset you have saved to. The POWER ON PRESET determines how the unit is configured upon power up.

If you have multiple Vortex devices in your system, save to a User Preset on each unit and set the POWER ON PRESET accordingly.

## *OTHER EF2211/EF2210 FEATURES*

---

For information on Macros, Logic Inputs (EF2211 only), Logic Outputs (EF2211 only), Input Filters and Output Filters, please refer to the Conference Composer User Guide.

# LCD MENU STRUCTURE

## LCD Menu Tree

The EF2211/EF2210 LCD menu structure is made up of nine menu trees: SYSTEM, PHONE CONTROL (EF2211 only), INPUTS, OUTPUTS, AUTOMIXER, MATRIX, PARAMETRIC EQ, PRESETS, and MACROS. Each menu tree is organized by levels and branches into multiple subcategories. The branches end with an adjustable parameter or value.




Figure 14. LCD Menu Tree.

DOWN	UP	ENTER	ESC	HOME
Scrolls backward through menu items at particular level or decreases the value of a parameter	Scrolls forward through menu items at particular level or increases the value of a parameter.	Enters the menu and allows you to select and change parameter values.	Returns to the top of the next highest level of menus	Returns to the top of the menu structure.

Table 2: Summary of button functions on the EF2211/EF2210.

The EF2211/EF2210 has five menu buttons on the front panel for navigation in the menu tree. Press the HOME button from anywhere in the menu tree to return to the top of the menu. The ENTER button enters the menu and the ESC button returns to the next highest level of menus. To scroll back through menu items at a particular level, use the DOWN button. To scroll forward through menu items at a particular level, use the UP button.

To adjust a parameter, first locate the parameter by scrolling to the appropriate menu (with combinations of the UP/DOWN and ENTER buttons). The display will show the

parameter field and the parameter value. To change the parameter, the parameter must be flashing. To make the parameter flash (assuming the front panel is not locked) press ENTER. Once the parameter is flashing, use the UP and DOWN buttons to adjust the parameter value. The parameter is instantly updated while it is being adjusted — you should hear changes as the parameter is changing. RS-232 control strings are also sent via the RS-232 port so your remote control device is instantaneously updated as well. Press ENTER to select and store the parameter value or press ESC to cancel the selected value and return to the old value. Pressing HOME has the effect of pressing ESC then HOME, so the selected value will be cancelled and the menu will return to the top of the menu tree.

Parameters that toggle or select among a list of options will wrap around when you reach the end, but parameters that adjust numeric values will not wrap around once the maximum or minimum value is reached. While adjusting a parameter, the UP/DOWN button must be held down briefly before the repeat rate increases.

## SYSTEM MENU

System
Power On Preset
Acknowledgement Mode
Bus Reference
Error Messages
Front Panel Lock
Front Panel Password
Device ID
Baud Rate
Flow Control
Meter
Non-Volatile Memory Lock
Non-Volatile Mem Password
Screen Saver
Last Restored Preset
Software Version
Reboot Vortex

**Figure 15.** EF2211/EF2210 System sub-menu

The SYSTEM menu contains POWER ON PRESET, ACKNOWLEDGEMENT MODE, BUS REFERENCE, ERROR MESSAGES, FRONT PANEL LOCK, FRONT PANEL PASSWORD, DEVICE ID, BAUD RATE, FLOW CONTROL, LCD CONTRAST, METER, NON-VOLATILE MEMORY LOCK, NON-VOLATILE MEMORY PASSWORD, SCREEN SAVER, SOFTWARE VERSION, and REBOOT EF2211/EF2210 configurations.

**Power On Preset.** Choose the EF2211/EF2210 Preset for power up.

**Acknowledgement Mode.** This command controls whether or not status messages are sent.

**EF Bus Reference.** This designates which EF2211/EF2210 device, when multiple devices are linked together, will put one of their echo canceller references on the EF bus to be used as the EF bus reference.

**Error Messages.** Turns error messages On or Off.

**Front Panel Lock.** Locks or unlocks the front panel. When the front panel is locked, you can see the parameters but you cannot change them.

The default passcode is `aspi` (case is important).

**Front Panel Passcode.** Once the device has been unlocked, the passcode may be changed. At the FRONT PANEL PASSCODE menu, press ENTER and then enter a passcode and press ENTER until you reach the end of the screen.

**Device ID.** Selects the Device ID of the unit.

**Baud Rate.** Selects baud rate of the RS-232.

**Flow Control.** Selects flow control between Hardware, None, or Auto.

**Meter.** Selects which signal is displayed on the front panel LED meter.

**Non-Volatile Memory Lock.** Controls the non-volatile lock feature. When the non-volatile memory is locked, you can query the settings but will get an error if you try to change them.

**Non-Volatile Memory Password.** This feature sets or queries the non-volatile lock password. This password is used in conjunction with NON-VOLATILE MEMORY LOCK. The default password is `aspi` (case is important).

**Screen Saver.** Enables or disables the screen saver on the LCD panel. You can also set the idle time.

**Last Restored Preset.** Displays the last restored Preset.


**Software Version.** Queries the software version.

**Reboot EF2211/EF2210.** Cycles power on the EF2211/EF2210.

---

*PHONE CONTROL (EF2211 ONLY)*

---



**Auto Answer.** Enables or disables auto answer.

**Auto Hangup Call Progress.** Enables or disables auto hangup based on call progress messages.

**Auto Hangup Loop Drop.** Enables or disables auto hangup based on loop drop.

**Country Select.** Selects the country where you are using the unit. This must be set before you can use the unit and does not need to be set again unless you use the unit in a different country.

**Dial Tone Gain.** Adjusts the gain of the dial tone.

**DTMF Gain.** Adjusts the gain of the DTMF tones.

**Ring Tone Enable.** Enables or disables ring tones.

**Figure 16.** EF2211/  
EF2210 Phone Control submenu

## INPUTS

Inputs 1, T, A, B
Acoustic Echo Cancellation (In 1)
Automatic Gain Control (AGC), In 1, T
AGC Maximum (In 1, T)
AGC Minimum (In 1, T)
Gain
Level Mic/Line (In 1)
Mute
Noise Cancellation (In 1, T)
Noise Cancellation Level (In 1, T)
Phantom Power (In 1)
Reference Assign (In 1)
AEC Suppression (In 1)
Dynamics Processing (In T)
LEC Suppression (In T)
Line Echo Cancellation (In T)

**Figure 17.** EF2211/EF2210 Inputs sub-menu

The input menu allows the user to adjust functions related to the input signals to the EF2211/EF2210. This menu contains ACOUSTIC ECHO CANCELLATION, AUTOMATIC GAIN CONTROL, AGC MAXIMUM, AGC MINIMUM, GAIN ADJUST, LEVEL MIC/LINE, MUTE, NOISE CANCELLATION, NOISE CANCELLATION LEVEL, PHANTOM POWER, REFERENCE ASSIGN, and AEC SUPPRESSION. The menu is organized around the Inputs (1, T, A and B), so that you first select an input and then select settings for that input.

NOTE: Input T is the incoming phone signal. This input is only available on the EF2211.

**Acoustic Echo Cancellation.** This allows you to enable or disable the acoustic echo canceller on channel 1. The default is On.

**Automatic Gain Control (Inputs 1, T).** This enables automatic gain control (AGC) on Input 1 and T. The default is On.

**AGC Max (Inputs 1, T).** Sets the maximum gain value that the AGC can apply for Inputs 1 and T.

**AGC Min (Inputs 1, T).** Sets the minimum gain value that the AGC can apply for Inputs 1 and T.

**Gain.** This parameter adjusts the gain level of the inputs. This is normally configured during the calibration process. **The default setting is 15 dB for microphone signals and 0 dBu for line level signals.**

**Level (Input 1).** Use this parameter to select mic or line level on Input 1.

**Mute.** This selects which input channel (1, T, A, B) is muted. The default is not muted.

**Noise Cancellation (Inputs 1, T).** This allows you to enable or disable noise cancellation.

**Noise Cancellation Level (Inputs 1, T).** Selects the level of noise cancellation. This ranges from 0 to 15 dB. The default is 10 dB.

**Phantom Power (Input 1).** Use this parameter to turn phantom power On or Off for input 1.

**Echo Canceller Reference (Input 1).** This parameter decides which reference is associated with the input. Choose between REF1 or the external bus reference.


**AEC Suppression (Input 1).** Sets the amount of double talk suppression used in the AEC. The values correspond to the following settings: 1 = No Suppression, 2 = Light Suppression, 3 = Heavy Suppression, 4 = Half-Duplex.

**Line Echo Cancellation (Input T).** Enables or disables the echo cancellation on the phone line.

**Dynamics Processing (Input T).** Enables or disables compression on Input T.

**LEC Suppression (Input T).** Sets the amount of suppression used the line echo canceller (LEC).

## OUTPUTS



**Figure 18.** EF2211/EF2210 Outputs sub-menu

The OUTPUT menu contains GAIN, NOM ACTIVE, and MUTE. As with the INPUT menus, this is done on a per channel basis.

NOTE: Output T is the outgoing phone signal. This output is only available on the EF2211.

**Output Gain.** Choose the gain applied to each output signal using this parameter. **The default setting is 0 dBu.** Though the EF2211/EF2210 allows for positive output gain, you should always try to adjust input gains to a good level so that the output gain is 0 dB. If you find that you need a positive output gain from the EF2211/EF2210, first check your input gain to make sure you are getting a good level (around 0dB). Keep the output gain at around 0 dBu. Then, for the best gain structure, use your amplifier to raise the volume in your system.

**Mute Output.** Use this to mute or unmute each Output.

**NOM Active.** This allows you to select whether the NOM attenuator is active for a particular output channel (Outputs 1, A, B, T). The NOM attenuator will attenuate the output signal by  $10 \cdot \log_{10}(\text{NOM})$  where NOM is the number of open microphones in that particular output channel. NOM is calculated based on the number of open microphones for each signal that is in the output.

**Output Delay Enable.** This allows you to enable delay to each of the outputs.

**Output Delay.** Sets the amount of delay on the output. The default value is 0 ms. The range is 0 to 340.0 ms in 0.1 ms increments.

**Dynamics Processing (Output T).** Enables or disables compression on Output T.

# AUTOMIXER MENU

**Automixer**


Global Settings

Mixer Settings

Channel Settings

**Figure 19.** EF2211/EF2210 Automixer submenu

These parameters configure how the Vortex automatic microphone mixer operates. Parameters include the following: DECAY TIME, HOLD TIME, CAMERA GATING THRESHOLD, BUS ID, CHAIRMAN MODE, CHAIRMAN MIC, LAST MIC ON MODE, LAST MIC NUMBER, LOCAL MAX NOM, GLOBAL MAX NOM, OFF ATTENUATION, AUTOMIXER, THRESHOLD TYPE, GATING MODE, ADAPTIVE THRESHOLD, MANUAL THRESHOLD, and GATE PRIORITY.



**Figure 20.** Automixer parameters.

## Global Settings.

**Decay Time.** Decay time is the amount of time the microphone audio takes to ramp down to the Off Attenuation level after Hold Time. Decay Time values range from 0 to 5000 msec. The default value is 1000 msec.

**Hold Time.** This is the amount of time the microphone stays On after the energy in the channel drops below the gating threshold. The default value is 500 msec. The range is 1 to 5000 msec. Microphone channels gating On and Off too frequently during short pauses in speech might be the result of setting the Hold Time too low while too many microphones gating on at the same time may be the result of Hold Time values that are too high.

**Camera Gating Threshold.** Specifies the hold time for camera gating information.

**Automixer**


**Global Settings**

Decay

Hold Time

Camera Gating Threshold

## Mixer Settings.



**Bus Mixer.** This command is used to assign one of the two internal automixers to one of the EF Bus automixer groups. Setting the Bus Mixer to the same number as the automixer on another Vortex device will allow the devices to be one large automixer. Setting Bus Mixer to 0 means that the automixer is not grouped on the EF Bus and the automixers operate independently.

**Chairman Mode.** Enables or disables Chairman Mode for the automixer.

**Chairman Mic.** Sets the Chairman Microphone for the automixer.

**Last Mic On Mode.** Sets “Last Mic On” mode for the automixer.

**Last Mic Number.** Sets the microphone number that will remain on when “Last Mic On” mode is set to manual. Setting this value to 0 will cause the automixer to leave the last open microphone on. The last microphone number is specified for the automixer, but is only used in manual “Last Mic On” mode.

**Local Max NOM.** Sets the maximum number of open microphones (NOM) limit for the automixer. This NOM limit is a “local” limit, meaning that this limit applies only to the specific Vortex device that it is set on.


**Global Max NOM.** Sets the global maximum number of open microphones (NOM) limit for each linked automixer. The maximum value for this command is 64. This NOM limit is a “global” limit, meaning that this limit applies to all linked automixers with the same Bus ID.

**Off Attenuation.** Sets the Off Attenuation (in dB) for the automixer. Setting this value to 18 would result in the microphone signals being attenuated by 18 dB when gated off. This value is set independently for the automixer.

**Automixer Reference.** When enabled, the echo canceller reference becomes a muted input in the automix so that far end audio coming from the speakers does not gate on local microphones.

**Reference Bias.** Adjusts how much gain is applied to the Automixer Reference signal. The higher the gain, the harder it will for local talkers to gate on a microphone.

## Channel Settings.



**Automixer.** This allows you to select between Mixer 1 or no automixer for the microphone channel input 1.

**Threshold Type.** Sets adaptive or manual automatic gating thresholds per input.

**Gating Mode.** Sets the automixer gating control mode for input channel 1. The possible modes are Normal Gating, Microphone Forced On, or Microphone Forced Off.

**Adaptive Threshold.** This allows you to determine when to gate a microphone on based on an estimate of the background noise level. The default value is to gate a channel on if it is more than 10 dB louder than the background noise level. Values range from 0 to 100 dB. To set the adaptive threshold, scroll through the adaptive threshold range and select the desired adaptive threshold by pressing ENTER.


**Manual Threshold.** Sets the automixer gating threshold for input channel 1. This value is only used if the input set to Manual Gating via the THRESHOLD TYPE option.

**Gate Priority.** The priority of each microphone can be assigned a value ranging from 1 to 4. Priority 1 microphones have priority over priority 4 microphones for gating. The default is to have all microphones set to priority 1. If Chairman Mode is enabled, all microphones including ones with priority of 1 will be gated off when the Chairman mic gates on.

---

## MATRIX MENU

---



**Figure 21.** EF2211/  
EF2210 Matrix sub-  
menu


The MATRIX contains commands for assigning input signals to output signals with appropriate gains applied or mutes applied. It also allows for Gating to be turned on for Input 1. This menu can apply gains to both the MAIN MATRIX and the SUBMATRIX.

**Crosspoint Gains.** Assign input signals to output signals with appropriate gains applied.

**Gate.** Applies gating from Input 1 to an Output.

**Mute.** Applies mute to the crosspoint.

## PARAMETRIC EQ MENU



**Figure 22.** EF2211/  
EF2210 Parametric  
EQ submenu

The input equalizer is comprised of up to 5 bands of filtering. The whole group of filters for the channel can also be enabled/disabled without losing the settings for each band. For each band, you first select the type of filter from the following: Parametric/Peaking, High Shelf, Low Shelf, Lowpass, Highpass, Linkwitz-Riley Low, or Linkwitz-Riley High.

### Parametric/Peaking.

- Center Frequency: in Hz, between 20 Hz and 20,000 Hz in 1 Hz steps.
- Bandwidth: in octaves, between 0.05 and 2 octaves in 0.05 octave steps.
- Gain: in dB, between -20 and +20 in 1 dB steps.

### High Shelf.

- Center Frequency: in Hz, between 20 Hz and 20,000 Hz in 1 Hz steps.
- Bandwidth: in dB/octave, between 1 and 24 dB/octave, but is always less than or equal to 1.2 x Gain.
- Gain: in dB between -20 and +20 in 1 dB steps.

### Low Shelf.

- Center Frequency: in Hz, between 20 Hz and 20,000 Hz in 1 Hz steps.
- Bandwidth: in dB/octave, between 1 and 24 dB/octave, but is always less than or equal to 1.2 x Gain.
- Gain: in dB between -20 and +20 in 1 dB steps.

### Lowpass.

- Cutoff Frequency: in Hz, between 20 Hz and 20,000 Hz in 1 Hz steps.

### Highpass.

- Cutoff Frequency: in Hz, between 20 Hz and 20,000 Hz in 1 Hz steps.

**Linkwitz-Riley Low.** •Frequency: in Hz, between 20 Hz and 20,000 Hz in 1 Hz steps

- Slope between 24 dB/oct and 12 dB/oct

**Linkwitz-Riley High.** •Frequency: in Hz, between 20 Hz and 20,000 Hz in 1 Hz steps

- Slope between 24 dB/oct and 12 dB/oct

Center frequency on Parametric/Peaking is the point with the most (or least) gain. Bandwidth is the width halfway up the peak (so if the peak is 10 dB, it is the width between the points where the gain is 5 dB).

Center frequency on shelving filters is the frequency where it crosses the point halfway between 0 dB and the gain of the filter, halfway up the slope.

---

## PRESETS

---

*Presets*

Restore

Save  
Presets 16-47

Delete  
Presets 16-47

**Restore.** Restores the selected preset.

**Save.** Saves the selected user preset (Presets 16-47). Factory presets (Preset 0-15) cannot be overwritten.

**Delete.** Deletes the selected user preset (Presets 16-47). Factory Presets (Presets 0-15) cannot be deleted.

**Figure 23.** EF2211/  
EF2210 Presets sub-  
menu

---

## MACROS

---

*Macros*

Run Macro (0-255)

**Run Macro (0-255).** Allows you to run macros from the front panel menu.

**Figure 24.** EF2211/  
EF2210 Macros sub-  
menu

---

## ***TROUBLESHOOTING***

---

### ***AUTOMATIC MICROPHONE MIXER***

---

#### **The microphone is not gating**

- Check if the microphone is assigned to an automixer.
- Check if the microphone is muted.
- Check microphone level. Is the microphone set to the appropriate mic or line level? Is phantom power on where needed?
- The Hold Time may be too low. Microphone channel gating On and Off too frequently during short pauses in speech might be the result of setting the Hold Time too low.
- Check Gating settings. Is the microphone Forced Off?
- Check Gating Priority. If your input has a Gating Priority of 4, the microphone may not gate as frequently.
- Adjust the Adaptive Threshold if the Gate Threshold is set to Adaptive or adjust the Manual Threshold if the Gate Threshold is set to Manual. For Adaptive Gate Threshold, set the Adaptive Threshold lower so that the microphone will gate On when lower level signals are present at the microphone. For Manual Gate Threshold, set the Manual Threshold to a lower absolute threshold.

### ***MATRIX MIXER***

---

#### **Don't hear output**

- Make sure the output is not muted.
- Check that the input you're expecting to hear is included in the output that you're listening to.

### ***ECHO CANCELLER REFERENCE***

---

#### **Room Audio Sounds Choppy**

If you hear the local room's audio from the loudspeakers and it sounds choppy, you may have included the room's microphones in the echo canceller reference. The echo canceller reference should NOT include the local room's microphones -- it should only contain the remote end's audio and program audio. You can still add the local room's microphones to the local output with the matrix, but do not add them to the echo canceller reference. For more specific guidelines on what to include in your echo canceller reference, see "Build Your Echo Cancellor Reference" on page 16.

### ***RESIDUAL ECHO***


---

You may hear residual echo if system levels are not set properly. Improper level settings anywhere in the audio path can introduce nonlinearities that hamper the opera-

tion of the EF2211/EF2210. If you hear residual echo, one of the following conditions may be causing the problem.

## Reverberation vs. Acoustic Echo

Do not confuse the residual echo of remote speech with the reverberation of local speech. Reverberation of local speech is caused when the speech signal arrives at the microphone via several paths (the direct path and multiple reflections from surfaces in the room). This is a local room phenomenon that gives the talker's voice a hollow or resonant sound (as heard at the remote end).



**Figure 25.** Reverberation vs. Acoustic Echo.

Reverberation is not an artifact of the echo canceller. It is mainly affected by the distance of the microphone from the speech source and by the resonances of the room. While reverberation can be unpleasant, it is not compensated for by the acoustic echo canceller (AEC), which only removes reflections of remote speech. If the remote end complains that they hear echo, ensure that they are referring to hearing their own voice and not echoes of local talkers.

You cannot remove the effects of reverberation by changing the EF2211/EF2210's settings, but you can minimize reverberation by moving microphones closer to talkers and, if necessary, adding acoustical treatment to the room.


## Finding the Source of Echo

Try muting one channel at a time to see if the echo that the remote end is hearing goes away when a particular channel is muted. If you find that the echo goes away when a particular channel is muted, the microphone may not be calibrated correctly. Check one or more of the following issues.

## Room Gain

The most common cause of poor echo cancellation performance is incorrectly adjusted room gain. This may be explained as follows. The reference signal seen by the AEC is sent to a loudspeaker output, where it is amplified and sent to the room

loudspeakers. The loudspeaker audio is coupled into the room microphones acoustically, through direct and reflected acoustic paths, and perhaps also through mechanical coupling. The microphone signal is then amplified and sent to the AEC as the local microphone input signal. The room gain of a microphone channel refers to the relative levels of the signal sent to the loudspeaker output (before any amplification) and the level of this signal that is reflected as the microphone input (after microphone amplification).



**Figure 26.** Room Gain.

If the electrical level of the reflected signal picked up by microphone is the same as the level of the electrical signal sent from the AEC to the loudspeaker output, the room gain of this microphone channel is said to be 0 dB. If the reflected signal picked up by the microphone is higher than the level of the signal sent to the loudspeaker output, that microphone channel has positive room gain. The more positive the room gain, the harder the AEC must work to determine which signal is an echo and which is a local speech signal.

## Excessive Room Gain

Excessive room gain can be caused through a number of mechanisms:

1. The most common is excessive amplification of the remote (reference) signal at the local loudspeaker output. This may be explained as follows. If the reference signal is too low coming into the EF2211/EF2210, i.e. the codec audio signal is too low, the room audio amplifier is usually used to compensate and bring the room audio to an acceptable level. For example, if the reference signal is 12 dB too low, the room audio will need to be amplified by approximately 12 dB to bring it to a reasonable listening level. This adds 12 dB to the room gain, which will most likely cause it to exceed the amplifier room gain limit (See “Verify Room Gain” on page 12). This situation can be remedied by applying enough gain to the codec, phone or program audio inputs (Inputs A-B) which will make up the Reference input signal so that the acoustic echo canceller (AEC) sees a good reference signal rather than trying to compensate at the amplifier.
2. Another common cause of room gain failure is excessive microphone amplification. For example, if a microphone is "hot" by 6 dB, then the reflections of the loudspeaker output signal which are picked up by the microphone will be ampli-

fied by 6 dB more than necessary. This adds 6 dB to the room gain, which may be sufficient to cause room gain problems. This situation could easily arise if, for example, the conferencing equipment is set up so that participants are too far from the microphone. In such a situation, after correct microphone setup the local microphone audio level may be too low because of the distance from the talker to the microphone. The microphone audio will most likely also be muddy and reverberant. The installer or user may try to solve these microphone audio quality problems by turning up the microphone amplification, thus adding to the room gain. This problem can be remedied by proper microphone selection (pickup pattern, directionality) and placement, coupled with proper microphone input calibration.

3. A third common cause of room gain problems is excessive coupling between loudspeaker audio and microphones. This can be addressed by reducing the microphone coupling, either by positioning microphones so that their pickup patterns are biased away from the loudspeaker audio (and direct reflections of loudspeaker audio), repositioning loudspeakers, or reducing the loudspeaker amplification.

In summary, any amplification applied between the reference input and the microphone input can add to room gain problems. To avoid problems, ensure that the Reference input signal is not too low, and the microphone input signals are not too high. Run the built-in EF2211/EF2210 Room Gain test to verify that you do not have room gain problems (See “Verify Room Gain” on page 12).

COMMON CAUSES OF EXCESSIVE ROOM GAIN	REMEDY
Excessive remote (reference) input amplification	Apply enough gain to the codec, phone or program audio inputs which will make up the Reference input signal.
Excessive microphone amplification	Select proper microphones for talker distance according to pickup pattern and directionality and properly calibrate mic input.
Excessive coupling between loudspeaker audio and microphones	Reduce mic coupling by repositioning mics or loudspeakers, or by reducing loudspeaker amplification.

**Table 3:** Summary of Excessive Room Gain.

## In-Conference Quick Check

If you experience residual echo problems during a conference, you can quickly check that the reference and microphone levels are calibrated and not causing room gain problems by using the Room Gain parameter (See “Verify Room Gain” on page 12).

If this excessive coupling activity level is evident on only one microphone input channel, that microphone channel should either be redirected to reduce coupling to loudspeaker audio, or recalibrated as it will need to be turned down. If the excessive coupling activity is observed on all (or most) microphone channels, then this indicates either that the room audio is too loud or the reference signal may need to be recalibrated (this will be indicated by observing low activity levels on the SIGNAL LEVEL METER).

## Excessive Microphone Amplification

For the EF2211/EF2210 to adapt effectively, saturation (overload or clipping) must not occur at the A/D converter supplying the microphone input. Saturation introduces nonlinear signal distortions into what the AEC expects is a linearly echoed version of the remote speech.

Nonlinear distortion causes a degradation or divergence of the AEC's internal model of the room acoustics. In this situation, the EF2211/EF2210 cannot effectively cancel room echoes and a substantial amount of echo may be heard by the remote party.

Excessive microphone amplification also increases room gain (See "Excessive Room Gain" on page 39.). You can check for excessive microphone amplification by observing the front panel LEVEL INDICATOR during a normal conference. The first yellow LED should illuminate frequently. If the second yellow LED is illuminated constantly during normal speech or if the red LED illuminates or even flickers, reduce the microphone input level.

**Note.** Before you readjust the microphone input levels, check to make sure you are looking at the correct channel on the LEVEL INDICATOR.

**Note.** If you adjust the MIC/LINE INPUT level, you will affect the room gain. Check to make sure that the room gain limit is not exceeded. See "Verify Room Gain" on page 12.

## Insufficient Microphone Amplification

Grossly insufficient microphone gain degrades EF2211/EF2210 performance and weakens the out-bound speech power level. This has the effect of reducing the signal-to-noise ratio of the microphone signal, which is analogous to raising the background noise level in the room. Because this noise is uncorrelated with the echoes within the room, the EF2211/EF2210's ability to adapt and cancel echoes will be less than optimal.

A second effect of insufficient microphone gain is that the power of the microphone input signal may be substantially lower than that of the remote input signal. This reduces the ability of the decision logic to determine whether the AEC should be in transmit, receive, or double-talk mode. This effect may reduce the effectiveness of the EF2211/EF2210 in canceling echoes.

You can check for insufficient microphone amplification by observing the front panel LEVEL INDICATOR during normal conferencing conversation. The first yellow LED should illuminate frequently. If the LEVEL INDICATOR never illuminates beyond one or two green LEDs during normal speech, increase the microphone's input level.

**Note.** Before you readjust the microphone input levels, check to make sure you are looking at the correct channel on the LEVEL INDICATOR.

**Note.** If you adjust the MIC/LINE INPUT level, you will affect the room gain. Check to make sure that the room gain limit is not exceeded. See "Room Gain" on page 38.

## Nonlinearity

Overdriving the loudspeaker or inserting a dynamics processor before the EF2211/EF2210 may distort the signal that the microphones see causing ineffective AEC operation. The EF2211/EF2210 relies on the linearity of the acoustic feedback path

— D/A, amplifier, loudspeaker, microphone, and A/D — to cancel acoustic echoes. If you overdrive the loudspeaker or insert a dynamics processor before the echo canceller, the acoustic reflections picked up by the microphone do not match the signal fed to the loudspeaker. They are distorted copies of this signal. The EF2211/EF2210 cannot effectively cancel this distorted signal.

If you suspect the loudspeaker is introducing nonlinearities into the room acoustic path, take these steps to minimize its influence on the echo canceller.

- Keep the loudspeaker's volume level at less than three-eighths of full scale. If higher volume is required, the EF2211/EF2210 should operate effectively at volume settings of up to 50 percent of full scale. At more than 50 percent, most audio systems and loudspeakers introduce significant nonlinearities. The EF2211/EF2210 may not adapt under these conditions, and echoes may be heard.
- If the loudspeaker has a bass control, lower it. Excessive bass can cause a *boomy* effect that is nonlinear. In addition, excessive bass may cause substantial mechanical coupling to the microphone through vibrations induced in the housings and support structures.
- Increase the separation distance between microphones and the loudspeaker. The EF2211/EF2210 handles up to 10 dB of room gain between the loudspeaker and the microphone. You may be exceeding this limit if the loudspeaker is pointed directly at the microphones or if the loudspeaker volume is excessive (loudspeaker placement is not critical, but it should not be pointed directly at the microphones).

## *CONTACTING TECHNICAL SUPPORT*

---

If these troubleshooting guidelines don't resolve the problem you are experiencing with the EF2211/EF2210, please check our web site (<http://www.polycom.com>) for the most current technical support information (go to Products & Services, then to Voice Products, then to Installed Voice Systems). If you have further questions, please contact us at:

Applications Engineering  
Polycom Installed Voice Business Group  
9040 Roswell Road  
Atlanta, GA 30350

Phone: (800) 932-2774  
Email: [vortex@polycom.com](mailto:vortex@polycom.com)

Before contacting us, please review the warranty and repair policy on page 56.

## ***TECHNICAL SPECIFICATIONS***

### MECHANICAL SPECIFICATIONS

Dimensions	19" (483 mm) W x 9.6" (244 mm) L x 1.75" (45 mm) H (full rack unit)
Weight	4 lb. (1.8 kg) dry 5.5 lb. (2.5 kg) shipping
Connectors	Audio: Mini (3.5mm) quick connect terminal blocks RS-232: DB9F EF Bus In/Out: RJ45 Phone In/Out: RJ11 * Control/Status: DB25F * Only applies to the EF2211.

### ELECTRICAL SPECIFICATIONS

Power	110 - 240 VAC; 47-63 Hz
Power Consumption	25 W
Phantom Power	24 V, software selectable

### AUDIO I/O

Microphone Input Level	-30 dBu to 0 dBu/-66 dBu to -33 dBu, nominal; software selectable
Line Input Level	-20 dBu to 0 dBu, nominal; software selectable
Line Output Level	-20 dBu to 0 dBu, nominal; software selectable
Input Impedance	>10 kOhms
Output Impedance	50 Ohms (drives 600 Ohms)
Headroom	20 dB, nominal
Loudspeaker Output, Power Amplifier	10 W, 4-16 Ohms

### PERFORMANCE SPECIFICATIONS

Frequency Response	20 Hz to 22 kHz
Acoustic Echo Cancellation Span	270 ms
Total Cancellation of AEC	> 65 dB
Convergence Rate of AEC	40 dB/second
Line Echo Cancellation Span	32 ms
Total Cancellation of LEC	> 65 dB
Convergence Rate of LEC	40 dB/second
Noise Cancellation	0 dB to 15 dB, software selectable
Control Inputs (EF2211 only)	Contact closure
Status Outputs (EF2211 only)	5V, 20 mA each

## COMPLIANCE

The Vortex EF2211/EF2210 complies with the ITU G.167 Recommendation for AEC, FCC part 15, and CE requirements.

### USA and Canada

**This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:**

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

#### NOTE

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

In accordance with part 15 of the FCC rules, the user is cautioned that any changes or modifications not expressly approved by Polycom Inc. could void the user's authority to operate the equipment.

This Class [A] digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [A] est conforme à la norme NMB-003 du Canada.

### US Telco requirements (EF2211 only)

This equipment complies with part 68 of the FCC Rules. Please refer to the labeling on equipment for the following information:

- Registration Number
- Ringer Equivalence
- Grantee's Name
- Model Number
- Serial Number and/or Date of Manufacture
- Country of Origin

*If requested this information must be provided to the telephone company*

#### Notes

- *This registered equipment may not be used with party lines or coin lines.*
- *If trouble is experienced the customer shall disconnect the registered equipment from the telephone line to determine if the registered equipment is malfunctioning and that if the registered equipment is malfunctioning, the use of such equipment shall be discontinued until the problem has been corrected.*

- *If, in the unlikely event that this equipment causes harm to the network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify you as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it necessary.*
- *The telephone company may make changes to its facilities, equipment, operations or procedures that could affect the operation of the equipment. If this happens the telephone company will provide advance notice so you can make the necessary modifications to maintain uninterrupted service.*

## REN

The REN is used to determine the quantity of devices that may be connected to the telephone line. Excessive REN's on the telephone line may result in the devices not ringing in response to an incoming call. Typically the sum of REN's should not exceed five (5.0). To be certain of the number of devices that may be connected to a line (as determined by the total REN's) contact the local telephone company.

## Automatic Dialing

WHEN PROGRAMMING EMERGENCY NUMBERS AND/OR MAKING TEST CALLS TO EMERGENCY NUMBERS

1. Remain on the line and briefly explain to the dispatcher the reason for the call.
2. Perform such activities in the off-peak hours, such as early morning or late evening.

## Telco Connector

*A FCC compliant telephone cord and modular plug is provided with this equipment. This equipment is designed to be connected to the telephone network or premises wiring using a compatible modular jack that is Part 68 complaint. See the rest of these installation instructions for details.*

## Canadian Telco Requirements (EF2211 only)

**NOTICE:** The Industry Canada label identifies certified equipment. This certification means that the equipment meets telecommunications network protective, operational and safety requirements as prescribed in the appropriate Terminal Equipment Technical Requirements document(s). The Department does not guarantee the equipment will operate to the user's satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations. Repairs to certified equipment should be coordinated by a representative designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system, if present, are connected together. This precaution may be particularly important in rural areas.

**Caution:** Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

**NOTICE:** The **Ringer Equivalence Number** (REN) assigned to each relevant terminal device provides an indication of the maximum number of terminals allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the Ringer Equivalence Numbers of all the devices does not exceed 5.

**NOTE** *The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.*

### **CE Mark LVD and EMC Directive**

The EF2210 has been marked with the CE mark. This mark indicates compliance with EEC Directives

89/336/EEC and 73/23/EEC. A full copy of the Declaration of Conformity can be obtained from Polycom Ltd, 270 Bath Road, Slough, Berkshire, SL1 4DX, UK.

### **CE Mark R& TTE Directive (EF2211 only)**

This EF2211 has been marked with the CE mark. This mark indicates compliance with EEC Directives 89/336/EEC, 73/23/EEC 1999/5/EC. A full copy of the Declaration of Conformity can be obtained from Polycom Ltd, 270 Bath Road, Slough, Berkshire, SL1 4DX, UK.

#### **Declaration of Conformity:**

Hereby, Polycom Ltd. declares that this EF2211 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

#### **Konformitetserklæring:**

Hermed erklærer Polycom Ltd., at indestående EF2211 er i overensstemmelse med de grundlæggende krav og de relevante punkter i direktiv 1999/5/EF.

#### **Konformitätserklärung:**

Hiermit erklart Polycom Ltd., dass der EF2211 die grundlegenden Anforderungen und sonstige maßgebliche Bestimmungen der Richtlinie 1999/5/EG erfüllt.

#### **Δήλωση Συμμόρφωσης:**

Δια του παρόντος, η εταιρεία Polycom Ltd. δηλώνει ότι η παρούσα συσκευή (δρομολογητής) EF2211 πληροί τις βασικές απαιτήσεις και άλλες βασικές προϋποθέσεις της Οδηγίας 1999/5/ΕΚ.

#### **Vaatimustenmukaisuusvakuutus:**

Polycom Ltd. vakuuttaa täten, että EF2211 on direktiivin 1999/5/EC keskeisten vaatimusten ja sen muiden tätä koskevien säännösten mukainen.

#### **Déclaration de conformité :**

Par la présente, Polycom Ltd. déclare que ce EF2211 est conforme aux conditions essentielles et à toute autre modalité pertinente de la Directive 1999/5/CE.

#### **Dichiarazione di conformità:**

Con la presente Polycom Ltd. dichiara che il EF2211 soddisfa i requisiti essenziali e le altre disposizioni pertinenti della direttiva 1999/5/CE.

**Verklaring van overeenstemming:**

Hierbij verklaart Polycom Ltd. dat diens EF2211 voldoet aan de basisvereisten en andere relevante voorwaarden van EG-richtlijn 1999/5/EG.

**Declaração de Conformidade:**

Através da presente, a Polycom Ltd. declara que este EF2211 se encontra em conformidade com os requisitos essenciais e outras disposições relevantes da Directiva 1999/5/CE.

**Declaración de conformidad:**

Por la presente declaración, Polycom Ltd. declara que este EF2211 cumple los requisitos esenciales y otras cláusulas importantes de la directiva 1999/5/CE.

**Överensstämmelseförklaring:**

Polycom Ltd. förklarar härmed att denna EF2211 överensstämmer med de väsentliga kraven och övriga relevanta stadganden i direktiv 1999/5/EG.

Australia (EF2211 only)

**Mains powered POT's Voice Telephony without Emergency 000 dialing**

Warning

This equipment will be inoperable when  
mains power fails

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

**Rest of World  
EMC CLASS A ITE**

**WARNING**

This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

**Installation Instructions\***

*Installation must be performed in accordance with all relevant national wiring rules.*

*L'Installation doit être exécutée conformément à tous les règlements nationaux applicable au filage électrique.*

**Plug acts as Disconnect Device\***

*The socket outlet to which this apparatus is connected must be installed near the equipment and must always be readily accessible*

## CONFERENCE SYSTEM DESIGN

Good audio or video conferencing is more than acoustic echo cancellation. Before installing the EF2211/EF2210, you should consider how your whole conference system will work together. The goals of conference system design are the following:

- Transmit intelligible speech
- Reproduce received speech intelligibly
- Prevent echoes
- Interface properly with transmission equipment
- High quality program audio
- Intelligible sound reinforcement (if needed)

### Noise and Reverberation

Intelligibility can be affected by noise and reverberation. Noise comes from various sources such as HVAC, computers, projectors, or traffic. Some ways to improve the Signal to Noise Ratio (SNR) in your system include placing microphones closer to the talkers, using electronic noise cancellation, and applying acoustical treatments. The EF2211/EF2210 is a great way to reduce noise in your system and improve the SNR. Polycom's patent pending noise cancellation algorithm, included in the EF2211/EF2210, removes up to 10 dB of ambient background noise and improves perceived quality as well as intelligibility.

Reverberation in a conference system can reduce intelligibility in a room. To reduce reverberation and increase intelligibility, use directional microphone and loudspeakers, place microphones closer to the talker, and use acoustical treatment.

### Consider Room Gain

When planning your conferencing system, you should also consider the room gain that will occur as a result of your microphone and loudspeaker placement. Room gain refers to the relative level of the audio going to your amplifier (remote end speech or telephone speech) and the level of this audio being picked up by the microphone. We recommend a room gain of 0 dB or less for the best results. But for difficult acoustic environments, the EF2211/EF2210, as well as any of the EF products, can handle up to 10 dB room gain, which means that it offers great flexibility in your conference system design.

To help you measure room gain, the EF2211/EF2210 includes a room gain detector. You should check your room gain after you have set up the EF2211/EF2210.




Figure 27. Room Gain.



EF2210









Figure 29. Inside the EF2210

## CONNECTOR PINOUTS



### REMOTE CONTROL



### EF Bus

The EF Bus uses RJ45 connectors. These should be used with category five twisted-pair cable. The total distance of the EF Bus should be less than 4.5 m.

The EF Bus must be connected so that the EF Bus In of one box is connected to the EF Bus Out of another. Connecting the EF Bus In to another EF Bus In (or Out to Out) will not work.

### Cat-5 Plug Pinout

- 1 - White/Orange
- 2 - Orange
- 3 - White/Green
- 4 - Blue
- 5 - White/Blue
- 6 - Green
- 7 - White/Brown
- 8 - Brown

### RJ11 Plug Pinout

- 3 - Ring
- 4 - Tip


Note: Other pins are not connected. The DAA is not affected by Tip and Ring wiring reversal.

### RS-232 Port (9600, 19200, 38400, 8-N-1)

The RS-232 port is wired as DCE. It accepts a male DB-9 connector. Only pins 2, 3, and 5 are required by the EF2211/EF2210 but pins 7 and 8 are supported. Connect pins straight through (do not use null modem).

1 DCD; 2 TXD; 3 RXD 4 DSR; 5 ground; 6 DTR; 7 CTS; 8 RTS; 9 No connection

Baud rate is selectable at 9600, 19200, or 38400.



### ***Input/Output Remote Control Port***

**Logic Input:** Pins 1-24 are inputs 1-24, respectively. Pin 25 is ground.

**Logic Output:** Pins 1-20 are outputs 1-20, respectively. Pins 21-25 are ground. Each ground pin should be used with only 4 outputs. For example, outputs 1-4 could be connected to LEDs, which are connected to ground pin 1.


LEDs can be used without series resistors (we have provided series resistors in the circuitry). For best results, LEDs with  $V_f=2.0$  V and  $I_f=20$  mA should be used. Larger values may be used, but may result in dimmer LEDs. An LED with  $V_f$  less than 1.4 V should not be used without additional series resistance.

### ***Power Supply Input***

The power supply input accepts a 5-pin DIN male connector. Only use the power supply provided by Polycom. Use of other power supplies will void the warranty.

1 Ground; 2 Ground; 3 +5Vdc @ 3 A; 4 -15Vdc @ 0.3 A; 5 +15Vdc @ 1.2 A

+5, ±15 VDC



### ***Mic/Line Input, Line Inputs, Line Outputs***

These audio connectors accept a mini (3.5 mm) 3 conductor terminal block (provided). See Note below for manufacturer information.

From left to right the conductors are positive signal, negative signal, and shield ground.

**Note** *The information below lists manufacturer information for the 3.5 mm terminal block connector that is compatible with the parts we use:*


Manufacturer: Phoenix Contact

Description: Mini-COMBICON 3-position plug, 3.5 mm pitch

Type Number: MC 1,5/3-ST-3.5 or MC 1,5/3-ST-3,5

Part Number: 1840379

## CONNECTING UNBALANCED RCA TO BALANCED TERMINAL BLOCK




**Figure 30.** Cable construction for connecting unbalanced RCA to balanced 3-conductor terminal block.

1. Connect RCA Tip to terminal block pin 1.
2. Connect RCA Ring to terminal block pin 2.
3. Connect terminal block pin 3 to Shield, and leave Shield floating on RCA end.

**Caution!** Do NOT connect the shield at both ends.

**Caution!** On the EF2211/EF2210, the terminal block pin 3 is connected to chassis ground. Under no circumstances should pin 3 be connected to pin 1 or to pin 2. Doing so will add noise to the audio signal.

## MAKING AN EF BUS TERMINATOR



**Figure 31.** The terminator

### Instructions

To make a terminator (for use when connecting EF2280s), use an RJ45 connector. Connect pin 3 to pin 6 with an 110 Ohm resistor. A terminator is not required for the EF2211/EF2210 as it is built in.

---

**ADDITIONAL NOTES**

---

- Caution!** *Failure to use all four screws to attach the EF2211/EF2210 to the rack may result in uneven loading and cause a safety hazard.*
- Caution!** *Ensure that the power supply is securely located such that it cannot become dislodged and fall. Such a fall could cause personal injury or equipment failure.*
- Caution!** *When mounting a EF2211/EF2210 in a rack, consideration should be given to airflow and operating ambient temperatures inside the rack. To ensure safe operation of the EF2211/EF2210, ambient operating temperatures inside the rack should not exceed 40 degrees Celsius. Allow 2 inches (51mm) of open space in front of the EF2211/EF2210, 2 inches (51mm) on either side, and 4 inches (102 mm) behind the unit for proper ventilation. Equipment should not be installed in the rack in such a way as to interfere with the ventilation of the EF2211/EF2210.*
- Caution!** *Consideration should be given to the connection of the equipment to the supply circuit and the effect that overloading of circuits could have an overcurrent protection and supply wiring. Appropriate consideration of equipment nameplate ratings should be used when addressing this concern.*
- Caution!** *Reliable earthing of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connection to the Branch (use of power strips).*

---

---

## ***WARRANTY INFORMATION***

---

---

<b>What is covered</b>	Any defect in materials or workmanship.
<b>For how long</b>	Two years.
<b>What we will do</b>	<p>If your Vortex EF2211/EF2210 product is defective and returned within two years of the date of purchase, we will repair or, at our option, replace it at no charge to you.</p> <p>If we repair your Vortex product, we may use new or reconditioned replacement parts. If we choose to replace your Vortex product, we may replace it with a new or reconditioned one of the same or similar design. The repair or replacement is warranted for either (a) 90 days or (b) the remainder of the original two-year warranty period, whichever is longer.</p>
<b>Limitations</b>	<p>Polycom shall not be responsible for special, incidental, indirect, or consequential damages resulting from any breach of warranty, or under any other legal theory, including but not limited to loss of profits, downtime, goodwill, damage to or replacement of equipment and property, and any cost of recovering, reprogramming, or reproducing any program or data stored in or used with Vortex products.</p> <p>Some states do not allow limitations on how long an implied warranty lasts, or the exclusion of incidental or consequential damages, so the above exclusions or limitations may not apply to you.</p>
<b>What we ask you to do</b>	<p>To obtain warranty service for your Vortex product, call us at (800) 932-2774 and we will issue a Return Material Authorization number (RMA#). Use the original packaging materials to return the product. Ship the product prepaid to:</p> <p style="padding-left: 40px;">Polycom IVB Returns Attention: Warranty Repair RMA# (<i>Must be on package</i>) 9040 Roswell Road Atlanta, GA 30350</p> <p>Please be sure to include your name, company, address, phone number, and a description of the problem. After repairing or replacing your Vortex product, we will ship it to you via a surface carrier of our choice at no cost to you. If you wish it shipped via a specific carrier at your cost, you must arrange it when you obtain the RMA#.</p> <p>Repair or replacement of your Vortex product is your exclusive remedy.</p>
<b>What this warranty does not cover</b>	This warranty does not cover defects resulting from accidents, damage while in transit to our service location, alterations, unauthorized repair, failure to follow instructions, misuse, fire, flood, lightning, acts of God, or use in those countries where such

use violates Part 779 of the Export Administration Regulations of the United States Department of Commerce.

If your Vortex product is not covered by our warranty, call us at (800) 932-2774 for advice about whether we will repair your Vortex product and for other repair information, including charges. Polycom, at its sole discretion, may replace rather than repair your Vortex product with a new or reconditioned one of the same or similar design. The repair or replacement is warranted for 90 days.

The limited warranties and remedies set forth above are exclusive and in lieu of all other warranties, whether oral or written, express or implied. Polycom specifically disclaims any and all implied warranties, including, without limitation, the warranties of merchantability and fitness for a particular purpose.

**No User Serviceable Parts**

This product contains no user serviceable parts. Please contact Polycom Installed Voice Business Group for repairs. Attempts to repair this product by an unauthorized technician will void your warranty.

**State Law Rights**

This limited warranty gives you specific legal rights, and you may have other rights that may vary from state to state.

---

---

## ***DEFINITION OF TERMS***

---

---

<b>Acoustic Echo</b>	Acoustic echo occurs in a conferencing or distance learning system when the remote speech played in the loudspeakers is picked up by microphones in the room and is transmitted back to the remote end. This transmitted signal is a delayed version of the original, which causes the echo.
<b>Acoustic Gain</b>	Acoustic gain is a term used in conjunction with sound reinforcement. It refers to how much louder the audio is with sound reinforcement compared to without sound reinforcement.
<b>Ambient Level</b>	The ambient level, also referred to as noise floor, is the background noise heard in a room when no one on the near or remote end is talking.
<b>Automatic Gain Control (AGC)</b>	Automatic gain control increases or decreases the gain on an audio signal to an acceptable value.
<b>Automatic Microphone Mixer</b>	A microphone mixer that turns microphone channels on and off based on the signal level going into the microphone.
<b>Convergence Rate</b>	Convergence rate refers to the amount of echo a line or acoustic echo canceller can cancel per unit time, typically expressed in dB/sec. Better echo cancellers have a higher (faster) convergence rate. This term is typically used to quantify the time it takes to completely remove the echo from a conferencing system. Echo occurs due to a complete change of the acoustic environment such as the beginning of a phone call in a conference, a change of microphone-speaker placement, or speaker volume adjustment.
<b>Crosspoint Mix Minus Bus</b>	A mix minus bus allows each Vortex device to create a mix of signals without its own. Each device in the system can create four mixes (W, X, Y, and Z) and place them on the bus. Each device also can create three mixes each from the W, X, Y, and Z busses of the other devices (for a total of 12 mixes). One mix is hardwired as a normal mix minus. That is, it is a unity gain mix of the signals from all other devices. The other two mixes can have crosspoint gains on the signals from the other devices.
<b>Echo Canceller</b>	An echo canceller estimates the echo in an audio signal by using a reference and pre-forms processing to eliminate the echo from the signal.

<b>EF Bus</b>	The EF Bus is a digital bus that includes the W, X, Y, and Z audio busses as well as the echo canceller reference and remote control information. It can be used to link multiple Vortex devices.
<b>Equalization</b>	Equalization is the process of adjusting frequency characteristics of an audio signal.
<b>Line Echo</b>	Line echo is caused by reflections of the audio signal from the telephone hybrid. The EF2211/EF2210 is an example of a device that includes a line echo canceller.
<b>Macros</b>	An arbitrary set of commands that can be replayed.
<b>Matrix Mixer</b>	A matrix mixer allows you to choose which inputs are included in each output. Some matrix mixers allow you to assign crosspoint gains to the inputs.
<b>Noise Cancellation</b>	Noise cancellation is a digital signal process that removes noise from an audio signal corrupted by real-world interferences such as HVAC, office noise, crowd noise, or road noise. Generally, there are two parts of a noise cancellation algorithm: a method to detect the noise and a method to remove the noise. The Polycom noise cancellation algorithm (patent pending) is capable of removing 10 dB or higher of noise with no degradation at all to the resulting speech signal. This method does not attenuate speech, and removes noise during both speech and idle periods.
<b>NOM</b>	NOM refers to the number of open microphones in a system.
<b>NOM Attenuation</b>	NOM attenuation is the gain applied to the overall system gain to the microphone signals to compensate for how many microphones are open. The amount of attenuation is calculated by $10 \cdot \log_{10}(\text{NOM})$ .
<b>NOM Bus</b>	A NOM bus carries signal information as well as NOM information (i.e., the number of open microphones in the system, NOM).
<b>Presets</b>	Presets correspond to configuration parameters that have been previously saved to EEPROM.
<b>Room Gain</b>	The room gain of a conferencing system refers to the relative levels of the signal sent to the line output to your amplifier (before any amplification) and the level of this signal that is reflected at the microphone input (after microphone amplification). If the electrical level of the reflected signal picked up by the microphone is the same as the level of the electrical signal sent from the AEC to the line output to your amplifier, the

room gain of this microphone channel is said to be 0 dB. If the reflected signal picked up by the microphone is higher than the level of the signal sent to the line output to your amplifier, that microphone channel has positive room gain. The more positive the room gain, the harder the AEC must work to determine which signal is an echo and which is a local speech signal.

# INDEX

## A

Acoustic Echo Cancellation, AEC .....	10, 16, 17, 30, 38, 39, 43, 49, 58
Automatic Gain Control (AGC) .....	30, 58
Automixer, Adaptive Threshold .....	20, 33
Automixer, Adaptive Threshold .....	37
Automixer, Automatic Microphone Mixer .....	18, 20, 32, 37, 58
Automixer, Camera Gating Threshold .....	19, 32
Automixer, Chairman Mic Mode .....	19, 20, 33
Automixer, Decay Time .....	19, 32
Automixer, Gate Priority .....	20, 33, 37
Automixer, Gating Mode .....	20, 33
Automixer, Global Max NOM .....	19, 33
Automixer, Hold Time .....	19, 32, 37
Automixer, Last Mic On .....	19, 33
Automixer, Local Max NOM .....	19, 33
Automixer, Manual Threshold .....	20, 33, 37
Automixer, Off Attenuation .....	19, 33
Automixer, Off Attenuation .....	19
Automixer, Threshold Type .....	20, 33

## B

Bus Mixer .....	19, 21, 33
-----------------	------------

## C

Calibration .....	14
Compliance .....	44
Conference Composer .....	4, 12, 14, 17, 18, 21, 25

## D

Device ID .....	8, 10
Digital Bus .....	23, 59

## E

Echo Cancellation .....	30
EF Bus .....	4, 5, 8, 9, 16, 17, 19, 21, 22, 23, 24, 43, 52, 59
EF Bus Reference .....	24, 28
Equalization .....	59

<b>F</b>	
Factory Default Settings, Preset 0 .....	9, 11, 14, 21
Front Panel Lock .....	28
<b>G</b>	
Ground .....	53
Ground, Chassis .....	54
Ground, Logic Input .....	53
Ground, Logic Output .....	53
Ground, Power Supply .....	53
Ground, RS-232 .....	52
Grounding, Pin 1 Compatible .....	6
<b>I</b>	
Inputs .....	5, 6, 14
<b>L</b>	
LCD Menu .....	5, 14, 17, 26
Line Echo Cancellation, LEC .....	43
Line Echo Canceller, LEC .....	59
Logic Input .....	5, 25, 53
Logic Output .....	5, 25, 53
<b>M</b>	
Matrix, Matrix Mixer .....	21, 34
Mic/Line Inputs, Line Inputs, Line Outputs .....	53
Mix Minus .....	23, 58
Multiple Vortex Devices .....	8, 11, 17, 20, 21, 22,
.....	24, 25, 59
<b>N</b>	
Noise Cancellation .....	30, 43, 49, 59
NOM .....	23, 31, 59
NOM Attenuation .....	59
NOM Bus .....	24, 59
Non-volatile Memory Lock .....	28
<b>O</b>	
Outputs .....	31
<b>P</b>	
P Bus .....	8, 16, 23
Parallel Remote Control .....	5
Phantom Power .....	14, 30, 43
Phone .....	5, 8, 16, 17, 23, 43, 59
Power Amplifier .....	5, 43

---

Power On Preset .....	11, 25
Presets .....	59
<b>R</b>	
Reference, AEC .....	16–17, 23, 30, 58, 59
Reverberation .....	49
Room Gain .....	12, 38, 59
RS-232, Serial Remote Control .....	4, 5, 8, 14, 23, 27, 30,
.....	43, 52
<b>S</b>	
Submatrix .....	21, 24, 34
<b>T</b>	
Technical Support .....	42
Terminal Block Connectors .....	4, 8, 53
Terminating the EF Bus, Terminators .....	9, 54
<b>V</b>	
Video Codec .....	17, 22

Polycom, Inc.  
Installed Voice Business Group  
9040 Roswell Road Atlanta, GA 30350  
Phone: (800) 932-2774  
[www.polycom.com](http://www.polycom.com)

Technical Support:  
(800) 932-2774  
[vortex@polycom.com](mailto:vortex@polycom.com)

Polycom<sup>®</sup>, Vortex<sup>®</sup>, and the Polycom logo are registered trademarks of Polycom, Inc. in the United States and various countries. Copyright © 2003 Polycom, Inc. All rights reserved.

P/N 1725-80103-001 Rev A

