




Poly Studio X50 Display Mounting Kit





Top of Display

Haut de l'écran Display, unten Parte superior de la pantalla Parte superiore del display Parte superior da tela Góra ekranu Kijelző teteje Toppen av displayet ディスプレイの上部 디스플레이 상단 显示屏顶部 顯示器頂部













Bottom of Display

Bas de l'écran
Display, oben
Parte inferior de la pantalla
Parte inferior de l'isplay
Parte inferior da tela
Dół ekranu
Kijelző alja
Bunnen av displayet
ディスプレイの下部
디스플레이 하단
显示屏底部









www.polycom.com/support

